


FODSPORTS



FX6

**GROUP INTERCOM HELMET
BLUETOOTH HEADSET**


Table of Content

1 Packing List	1
2 Function Introduction	1
3 Installation Step	2
3.1 Fixed by clamp	2
3.2 Fixed by VELCRO sticker	4
4 Disassembly of device	4
5 Product Introduction	5
6 Button Operation Introduction	6
6.1 ON/OFF Button	6
6.2 Mutil-funtion Button	7
6.3 Knob	8
7 Bluetooth Status Indicator and Prompt	8
8 Pairing Methods	9
8.1 Two ways for FX6 to enter paired state	9
8.2 Pairing with any bluetooth headset	9
8.3 Pairing with Mobile Phone,GPS and MP3	10
8.4 Pairing between two FX6	10
8.5 Group intercom settings	11
8.6 Simultaneous connection of multiple devices	12
9 Priority of Function	13
10 Specification	13
11 Matters Needing Attention	14
12 After-Sale Service	14

1.Packing List



Bluetooth
Device



Microphone &
Ear Speakers



Clamp



Velcro Clamp



Manual



Headphone
Velcro



USB Cable



Screw Driver

2.Function Introduction



Fleet communication



Connect to any
bluetooth headset



Simultaneous connection
of multiple devices



Operating range
1000 meters



Connected with
2 mobile phones



Stereo music
A2DP



Voice dial



Voice prompt



Usable during recharging



Bluetooth 5.0



FM radio



Connected with two-way radio



Playback control




Water-proof



Advanced noise control

3. Installation Step


3.1 Fixed by clamp



1. Loosen the screws on the back of clamp with the provided screw driver.




2. Open the lining of helmet, insert the clamp in the proper position on the left of helmet and fasten the screw.




3. Slide the back track of the device into the clamping track.




4. Open the inner lining on the ear position of the helmet and attach the VELCRO loop.



5. Attach the Headphone Velcro hook to the loop (the short-line speaker is on the left).




6. Place butterfly sticker in the right position on the left side of the helmet, match the microphone with the mouth position, and tidy up the cable and lining.




7. Insert the plug into the headset socket and the installation is finished.

3.2 Fixed by VELCRO sticker




1. Slide the back track of the device into the clamping track.




2. Tear off the white paper on the back of the clamp and stick it in the right position on the left side of the helmet.

3. Ear speakers & Microphone installation step refer to 3.1

4. Disassembly of the Device





1. Pull out the headset plug.




2. Press the upper clamp buckle and move the device upward to remove it.

5. Product Introduction




6. Button Operation Introduction

6.1 On/Off Button




- **Turn on** (When the headset is off, press and hold it for 3 seconds. There is a “Welcome to FODSPORTS Bluetooth Communication System” sound prompt, and the blue light will be on for 1 second.)
 - **Turn off** (When the headset is on, press and hold it for 5 seconds. There is a “Power Off” sound prompt, and the red light will be on for 1 second.)
 - **Pairing** (When the headset is off, press and hold it for 6 seconds. There is a “Pairing” sound prompt, and blue and red lights flash alternately.)
 - **Clear the pairing device** (When the headset is on, keep pressing the button for another 3 seconds after turn it off. After “power off” sound prompt, the red light quickly flashes 3 times and a “toot” sound prompt can be heard.)
 - **Start the Bluetooth Intercom** (When paired, press once on the button, you will hear an “Intercom Connected” sound prompt When the connection is successful, then press again to disconnect the intercom, press again to reconnect.)
- Note:** If B pair with A & C successively, B need to press the button once to initiate intercom with C, and press twice to intercom with A.
- **End the Bluetooth Intercom** (Shortly press the button and intercom closes after a “Intercom disconnected” sound prompt.)

6.2 Multi-function Button



- **Pairing** (When the headset is on, press and hold it for 6 seconds. There is a “Pairing” sound prompt, blue and red lights flash alternately.)
 - **Answering a call** (When there is coming call, click it once to pick up or take no action, the headset will pick it up automatically, you will hear “Dong Dong” sound prompt.)
 - **Rejection of call** (If there is a call, press and hold it 2 seconds to reject, you will hear “Dong Dong” sound prompt.)
 - **Disconnect headset temporarily & answer by phone** (During a call, press and hold it for 2 seconds. There is a “Dong” sound prompt, and the red light flash every other second.)
 - **End a call** (Click it once on call will end it, there is a “Dong” sound prompt.)
 - **Voice dialing** (If you are not on a call, click it twice and there is a “Voice Dial” sound prompt.) **NOTE: Please make sure that your phone supports voice command and the functions are turned on.**
 - **Music Play/Pause** (When connected, click it once.)
 - **Switch between bluetooth and FM** (When the headset is on, triple-click it and there is “Bluetooth mode” or “FM mode” sound prompt.)
- *Turn on/off FM: When device is on, short press Multi-function Button 3 times to Switch on / off FM function.**

6.3 Knob



- **Turn up the volume** (On a call , intercom, playing music or FM, turn the knob clockwise and hold it to increase volume until it reaches the level you want . A “toot” prompt will be heard when it reaches Max volume.)
- **Turn down the volume** (On a call , intercom, playing music or FM, turn the knob counter clockwise and hold it to decrease volume until it reaches the level you want . A “toot” prompt will be heard when it reaches Min volume.)
- **Play the next** (When playing music or FM, turn the knob clockwise .)
- **Play the previous** (When playing music or FM, turn the knob counter clockwise .)

7. Bluetooth Status Indication and Prompt

- **Power on status** (If Bluetooth is connected, there is a “Bluetooth connected” sound prompt ,the blue indicator light flashes once every 6 seconds; if Bluetooth is not connected, there is a “Bluetooth disconnected” sound prompt , the blue indicator light flashes twice every 6 seconds.)
- **Low battery alarm** (The “Battery Low” sound is prompted every 60 seconds when turn on, red light will keep flashing.)
- **Charging status** (Red light is on when charging and off when fully charged.)

Battery status sound prompt when powered on (If the battery is full, the “Battery

Full” sound is prompted. If the battery is low, the “Battery Low” sound is prompted.)

8. Pairing Methods

8.1 Two ways for FX6 to enter pairing status

8.1.1 **Mode 1:** When the headset is off, press and hold On/Off Button for 6 seconds. There is a “Pairing” sound prompt, blue and red lights flash alternately.

8.1.2 **Mode 2:** When the headset is on, press and hold Multi-function Button for 6 seconds. There is a “Pairing” sound prompt, and blue and red lights flash alternately.

8.2 Pairing with the Non-Fodsports FX6 Bluetooth device



Step 1: Place the FX6 and the device within a visible range of 1 meter.

Step 2: Set the Non-FX6 Bluetooth device into pairing status.


Step 3: Follow step (8.1.2), FX6 enters pairing status.

Step 4: Short press FX6 on/off button to search the device, the “intercom connected” sound prompt means the 2 items are successfully paired.

Note 1: In step 4, the intercom connection must be initiated by FX6.

Note 2: When intercom, press FX6 on/off button to disconnect the intercom, then press again to reconnect.

8.3 Pairing with Mobile, GPS and MP3



Step 1 : Place the "FODSPORTS FX6" and the device within a visible range of 1 meter.

Step 2 : Follow step (8.1.1), "FODSPORTS FX6" enters pairing status

Step 3 : Turn on the device Bluetooth, search "FODSPORTS FX6" and connect. The "connected" sound prompt means the connection is successful.

8.4 Pairing between two FX6




Step 1 : Ensure both FX6 are off and within 1 meter visible range.

Step 2 : Follow step (8.1.1), both FX6 are in pairing status.

Step 3 : Short press the multi-function button or on/ off button on either FX6 to search the other one, you will hear "intercom connected" when successfully paired.

(NOTE: In the pairing status, short press multi-function button on either FX6 to search, can be used for connection between 2 FX6 only. For other non-FX6 device, you have to press the on/ off button.)

8.5 Group Intercom Settings



Note: For group intercom, the first and last FX6 CAN NOT be paired.

Step 1 : Clear the matching record between A and F

Press and hold the on/off buttons of A and F for 6 seconds until you hear sound prompt “power off ”, then hold them for another 3 seconds.

Step 2 : Refer to the matching operations in 8.4 for following operations


1. Pair A and B, turn off B after successfully paired;
2. Pair B and C, turn off C after successfully paired;
3. Pair C and D, turn off D after successfully paired;
4. Pair D and E, turn off E after successfully paired;
5. Pair E and F.

Step 3 : Connect A, B, C, D, E and F in series

1. For D, press the on/off button to connect with E;
2. For C, press the on/off button to connect with D;
3. For B, press the on/off button to connect with C;
4. For A, press the on/off button to connect with B.




*** E and F are connected completed after the Step 2 , Now A, B, C, D, E and F are all**

matched successfully, you can enter group intercom.



Note: During the 6 people group intercom, if D receives a call, D will be disconnected temporarily from the group. A, B and C form a group, E and F form a group. After D finished call, D will be reconnected into the group intercom automatically and the 6 people group intercom resumes.

8.6 Simultaneous connection of multiple devices



Note: Please DO NOT pair FX6 with mobile phone before you pair it with Bluetooth headset, otherwise, it may cause intercom communication error. It won't happen if FX6 is not connected with phone.

9. Priority of Functions

Level 1: Phone call & Intercom by introduced adapter.

Level 2: Intercom introduced by Two-way radio cable.

Level 3: Bluetooth Intercom

Level 4: FM & Music

10. Specifications

Bluetooth Version	5.0
Operating Range	Up to 1000 meters
Standby Time	Up to 200 hours
Operating Time	Up to 10 hours
Charging Time	Approximately 2.5 hours
Charging Interface	Micro USB Android universal plug
Battery Type	Rechargeable Li-Polymer battery
Power Supply	5V – 0.5A
Operating Temperature	14F-131F (-10°C-55°C)
Storage Temperature	-4F-140F (-20°C~60°C)

* The actual time may vary from the phone type and usage.

* The working distance will be deviated for the influence of environment and climate

11. Matters Need Attention

1.The Bluetooth name is "FODSPORTS FX6".



2.The appropriate storage temperature for this device is between -20°C and 60°C . Please do not store it in environment with too high or too low temperatures, otherwise the service life will be affected.


3.To avoid explosion, please do not expose it to open fire.

4.If you're not using it for a long time, please keep the device in dry place and charge it regularly (once every 3 months), to preserve battery life.

12. After-Sale Service

For any quality problem or missing accessories, especially pairing problem between 2 or more FX6 headsets, please feel free to contact us at email: winzon.cs@outlook.com. We're always here ready to help, will reply to you in 12 hours.

FODSPORTS



FX6

グループインターコム
ヘルメットBluetoothヘッドセット


目次

1. 付属品の確認	1
2. 機能の紹介	1
3. 取り付け方法	2
3.1 クランプで固定	2
3.2 ベルクロステッカーで固定	4
4. デバイスの分解	4
5. 製品の紹介	5
6. ボタン操作の紹介	6
6.1 オン/オフボタン	6
6.2 多機能ボタン	7
6.3 つまみ	8
7. Bluetoothステータスの表示とプロンプト	8
8. ペ어링方法	9
8.1 FX6をペ어링状態にする2つの方法	9
8.2 Bluetoothヘッドセットとのペ어링	9
8.3 携帯電話、GPS、M P3とのペ어링	10
8.4 2つのFX6とペ어링	10
8.5 グループインターコム設定	11
8.6 複数のデバイスの同時接続	12
9. 機能の優先順位	13
10. 規格	13
11. 注意が必要な事項	14
12. アフターサービス	14

1.付属品の確認



Bluetooth
デバイス



マイク&イ
ヤスピーカー



クランプ



マジッ
クテープ



マニュアル



ヘッドフォン
ベルクロ



USBケーブル



スクリウド
ライバー

2.機能の紹介



集団でのコミュニ
ケーション



大部のBluetoothヘ
ッドセットに接続可能



同時に複数デバ
イスを接続可能



1000メートル範
囲で操作可能



携帯電話2台
と接続可能



ステレオミュー
ジックA2DP



音声ダイヤル



音声プロンプト



充電中に使用可能



Bluetooth 5.0



FMラジオ



双方向ラジオ
と接続可能



プレイバック
コントロール




防水



高度なノイズ
制御

3. 取り付け方法


3.1 クランプで固定



1. 付属のドライバーを使用して、クランプ背面のネジを緩めます。




2. ヘルメットの裏地を開き、ヘルメット左側の正しい位置にクランプを挿入し、ネジを締めます。



3. デバイスのバックラックをクランプトラックにスライドさせます。




4. ヘルメットの耳の位置にある内側の裏地を開き、VELCROループを取り付けます。



5. ヘッドフォンのベルクロフックをループに取り付けます(ショートラインスピーカーは左側にあります)。



6. バタフライステッカーをヘルメットの左側の正しい位置に配置し、マイクを口の位置に合わせて、ラインと裏地を調整します。




7. プラグをヘッドセットソケットに挿入したら、インストール完了です。

3.2 VELCROステッカーで固定




1. デバイスのバックトラックをクランプトラックにスライドさせます。




2. クランプの背面にある白い紙をはがし、ヘルメットの左側の正しい位置に貼り付けます。

3. イヤスピーカーとマイクのインストール手順は3.1を参照してください。

4. デバイスの分解





1. ヘッドセットプラグを引き出します。



2. 上部のクランプバックルを押し、デバイスを上に動かして取り外します。

5. 製品の紹介




6. ボタン操作の紹介

6.1 オン/オフボタン



- ・ **電源を入れる** (ヘッドセットがオフのときは、3秒間押し続けます。「FODSPORTS Bluetooth通信システムへようこそ」という音声プロンプトが聞こえ、青色のライトが1秒間点灯します。)
 - ・ **電源を切る** (ヘッドセットがオンのときは、5秒間押し続けます。「電源オフ」の音声プロンプトが聞こえ、赤色のライトが1秒間点灯します。)
 - ・ **ペアリング** (ヘッドセットがオフのときは、6秒間押し続けます。「ペアリング」の音声プロンプトが聞こえ、青と赤のライトが交互に点滅します。)
 - ・ **ペアリングデバイスをクリアする** (ヘッドセットがオンのときは、ボタンを3秒間押し続け、「電源オフ」の音声プロンプトが聞こえてから、赤色のライトが3回点滅して「ピー」という音声プロンプトが聞こえるまで押し続けます。)
 - ・ **Bluetoothインターコムを開始する** (ペアリングが完了したら、ボタンを1回押すと、「インターコムが接続されました」の音声プロンプトが聞こえます。接続が成功したら、もう一度押してインターコムを切り、さらにもう一度押して再接続できます。)
- 注意:**—BがA & Cと同時に接続時、Bはボタンを2回押してAとのインターコムを開始し、ボタンを1回押してCとのインターコムを開始する必要があります。
- ・ **Bluetoothインターコムを終了する** (ボタンを短く押すと、「インターコムが切断されました」という音声プロンプトが聞こえた後、インターコムが終了します。)

6.2 多機能ボタン



- ・ **ペアリング**(ヘッドセットがオンのときは、6秒間押し続けます。「ペアリング」の音声プロンプトが聞こえ、青と赤のライトが交互に点滅します。)
 - ・ **電話に出る**(接続した状態で電話がかかってきた場合は、1回押すか、あるいは10秒間ぐらい何もしない。電話は、「ポーン」という音声プロンプトとともに自動的に接続されます。)
 - ・ **電話を拒否する**(電話がかかってきた時に、ボタンを2秒間押し続けます。「ポーン」という音声プロンプトとともに拒否されます。)
 - ・ **Bluetoothヘッドセットと携帯電話本体の音声切り替え**(通話中、ボタンを2秒間押し続けます。「ポーン」という音声プロンプトが聞こえ、1秒おきに赤色のライトが点滅します。)
 - ・ **通話を終了する**(通話中にボタンを1回押すと、「ポーン」という音声プロンプトが聞こえます。)
 - ・ **音声ダイヤル**(通話中でない、ヘッドセットが占有されていない場合に、ボタンを2回押すと、「ボイスダイヤル」の音声プロンプトが聞こえます。)
- 注意:**スマホが音声コマンドをサポートする機能がオープンしていることを確認する必要があります。
- ・ **音楽の再生/停止**(接続中は、ボタンを一回押してください。)
 - ・ **BluetoothとFMを切り替える**(ヘッドセットがオンのときに、ボタンを3回押すと、「Bluetoothモード」または「FMモード」の音声プロンプトが聞こえます。)
- *FMのオン/オフ:**多機能ボタンを3回短く押して、オン/オフを切り替えます。

6.3 つまみ



- ・ **音量を上げる** (通話、インターホン、音楽またはFMの再生時に、ノブを時計回りに回すと自由にボリュームを上げられます。最大音量に達すると、「ピー」と言う音声プロンプトが聞こえます。)
- ・ **音量を下げる** (通話、インターホン、音楽またはFMの再生中に、ノブを反時計回りに回すと自由にボリュームを下げられます。最小音量に達すると、「ピー」と言う音声プロンプトが聞こえます。)
- ・ **次の項目を再生する** (音楽やFMの再生中に、ノブを時計回りに回します。)
- ・ **前の項目を再生する** (音楽やFMの再生中に、ノブを反時計回りに回します。)

7. Bluetoothステータスの表示とプロンプト

- ・ **電源オンの状態** (Bluetoothが接続されている場合、「Bluetooth接続済み」という音声プロンプトが聞こえ、6秒ごとに青いインジケータライトが点滅します。Bluetoothが接続されていない場合、「Bluetooth未接続」という音声プロンプトが聞こえ、6秒に2回青いインジケータライトが点滅します。)
- ・ **充電が少ない時のアラーム** (電源をオンのときは、「バッテリー残量が少なくなりました」という音が60秒ごとに聞こえ、インジケータライトが赤色の点滅に変わります。)
- ・ **充電中の状態** (充電中は赤いライトが点灯します。充電が完了すると赤いライトは消えます。)
- ・ **電源オンの時のバッテリー状態** (バッテリーが十分のときは、「バッテリーがいっぱいです」という音が聞こえます。バッテリー残量が少ない場合、「バッテリー残量が少なくなりました」という

音が聞こえます。)

8. ペ어링方法

8.1 FX6をペアリング状態にする2つの方法

8.1.1**モデル1:** ヘッドセットがオフの状態、オン/オフボタンを6秒間押し続けます。「ペアリング」の音声プロンプトがあり、青と赤のライトが交互に点滅します。

8.1.2**モデル2:** ヘッドセットがオンの状態で、多機能ボタンを6秒間押し続けます。「ペアリング」の音声プロンプトがあり、青と赤のライトが交互に点滅します。

8.2 非Fodsports FX6インターホン機能Bluetoothデバイス(違う型番)とのペアリング



手順1: FX6とデバイスを目に見える1メートル範囲内に置き、

手順2: Non-Fodsports FX6 Bluetoothデバイスをペアリングの状態に設定します。


手順3: 手順 (8.1.2) に従い、FX6をペアリング状態にします。

手順4: FX6のオン/オフボタンをすばやく押しすと、ペアリングするデバイスが検索されます。「インターコム接続」の音声プロンプトが聞こえたら、接続完了です。

注意1: 手順4では、FX6からインターコム接続を開始する必要があります。

注意2: インターコムの場合、FX6オン/オフボタンを押してインターコムを切断し、再度押して再接続します。

8.3 携帯電話、GPS、MP3とのペアリング



手順1: "FODSPORTS FX 6"とデバイスを目に見える1メートル範囲内に置き、

手順2: 手順8.1に従い、"FODSPORTS FX 6"をペアリング状態にします。

手順3: デバイスのBluetoothをオンにし、"FODSPORTS FX 6"を検索して接続します。「接続されました」の音声プロンプトが聞こえたら、接続完了です。

8.4 2つのFX6とペアリング




手順1: 両方のFX6を目に見える1メートル範囲内に置き、どちらもオフになっていることを確認します。

手順2: 手順(8.1.1)に従い、両方のFX6をペアリング状態にします。

手順3: FX6のオン/オフボタンや多機能ボタンを短く押すと、ペアリングするデバイスが検索されます。「インターコム接続」の音声プロンプトが聞こえたら、接続完了です。(注:ペアリング状態で、多機能ボタンを短く押ししてFX6との検索やペアリングができます。Non-Fodsportsインターコム機能・のBluetoothデバイスとの接続の場合、オン/オフボタンしかペアリングできません。)

8.5 グループインターコム設定



注意: AとFをペアリングすることはできません。

手順1: AとFのマッチング履歴をクリアします。

AとFのオン/オフボタンを6秒間押し続け、「電源オフ」の音声プロンプトが聞こえてから、赤色のライトが3回点滅して「ピー」と言う音声プロンプトが聞こえるまで押し続けます。)

手順2: 次の操作については、8.4の対応する操作を参照してください。


1. AとBをマッチング、完了した後にBを切ります。
2. BとCをマッチング、完了した後にCを切ります。
3. CとDをマッチング、完了した後にDを切ります。
4. DとEをマッチング、完了した後にEを切ります。
5. EとFをマッチングします。

手順3: A、B、C、D、E、Fを直列に接続します。

1. Dの場合、オン/オフボタンを押してEと接続します。
2. Cの場合、オン/オフボタンを押してDと接続します。
3. Bの場合、オン/オフボタンを押してCと接続します。
4. Aの場合、オン/オフボタンを押してBと接続します。




* EとFはステップ2の後で接続が完了しました、これで、A、B、C、D、E、Fがすべて正常にマッチ

ングされたら、グループインターコムに参加できます。



注意: 6人のグループインターコム中にDが電話を受けた場合、Dは一時的にグループから切断されます。A、B、Cが一つのグループを、EとFがもう一つのグループを形成します。Dの通話が終了すると、Dは自動的にグループインターコムに再接続され、6人のグループインターコムが再開します。

8.6 複数のデバイスの同時接続



注意: インターコム通信エラーが発生可能性があるから、Bluetoothヘッドセットとペアリング前にFX6とスマホとのペアリングをしないでください。

9. 機能の優先順位

レベル1: インターコム管理者による電話とインターコム。

レベル2: 双方向無線ケーブルによって参加されたインターコム。

レベル3: Bluetoothインターコム

レベル4: FMと音楽

10. 規格

バージョン	5.0
作動範囲	最大1000メートル
待機時間	最大200時間
作動時間	最大10時間
充電時間	約2.5時間
充電インターフェース	Micro USB Androidユニバーサルプラグ
バッテリータイプ	充電式リチウムポリマー電池
電源供給	5V - 0.5A
作動温度	14F-131F (-10°C-55°C)
保管温度	-4F-140F (-20°C~60°C)

*電話の種類と使用状況に応じて、実際の時間は異なる場合があります。

*環境や気候の影響により、作動距離にずれが生じる場合があります。

11. 注意が必要な事項

1. Bluetooth名は「FODSPORTS FX 6」です。



2. このデバイスの適切な保管温度は、-20°C～60°Cです。温度が高すぎるまたは低すぎる環境で保管しないでください。耐用年数に影響を及ぼす可能性があります。
3. 爆発を防ぐため、直火にさらさないでください。
4. 長期間使用しない場合はデバイスを乾燥した場所で保管し、定期的に（3か月に1回）充電して、正常に機能することを確認してください。

12. アフターサービス

商品についてご質問やご相談などがございましたら、お気軽にお問合せください、24時間以内で対応させていただきます。

お問合せメールアドレス：faltus_jp@qq.com



User Manual Download



<https://community.fodsports.com/support/fx6-user-manual/>

FODSPORTS



<https://www.fodsports.com/>

CE FC

RoHS
COMPLIANT



MADE IN CHINA